



CRITICAL DETAIL:

ENERGY + HEALTH PROGRAM


BATHROOM EXHAUST FAN INSTALLATION (NO EXISTING FAN)

1. Select the bath fan location in the attic. Select a location close to the tub or shower. Trace the outline of the fan onto the drywall.



✓ LOCATE FAN

2. In the attic, drill two small pilot holes in opposite corners of the traced template.



✓ DRILL PILOT HOLES

3. In the bathroom, trace the outline of the fan on the ceiling, using the pilot holes as a guide.




✓ TRACE OUTLINE

4. In the bathroom or attic, carefully cut the fan hole. Support the piece while cutting to prevent chipping or tearing.




✓ CUT HOLE

5. Install the new fan according to the manufacturer's instructions. Install the fan with the exhaust port aimed at the exterior termination.



✓ INSTALL FAN

6. Caulk all of the cracks between the drywall and the housing unit and all holes in the housing unit.



✓ AIR SEAL

7. Select the type of duct to install and follow the appropriate critical detail



✓ INSTALL DUCT

8. Turn on power to bath fan at circuit panel. Verify fan and light (if applicable) work. Test fan air flow. (See Bath Fan Information Sheet)



✓ TEST AIR FLOW