



CRITICAL DETAIL:


EXHAUST FAN: METAL DUCT INSTALLATION

ENERGY + HEALTH PROGRAM

1. Select the fitting and ducts needed. For a roof termination, install a 90 degree fitting first. For a wall termination, use a straight fitting.



2. If a termination is not installed, follow the exhaust fan termination installation critical detail.



3. Install duct pieces with crimped ends pointed in the direction of air flow. Cut pieces to fit with tin snips.



4. For the connection between the duct and the termination, install the duct adaptor supplied with the termination cap.



5. Secure duct pieces together at the overlapping joints with self-tapping sheet metal screws. Place screws on opposite sides of overlap.



6. Seal all seams and joints with bucket mastic.



7. If installing a bath fan duct in unconditioned space, wrap the duct with insulation and seal the seams with mastic.

